Bipolar Junction Transistor and Hetero-junction Bipolar Transistor

Electronic Devices Lab: Experiment 7

Department of Electrical Engineering Indian Institute of Technology, Bombay



Background Information

- BJT is a 3-terminal 2-junction transistor that is used in high-frequency applications (such as RF circuits).
 It has three terminals: Base (B), Collector (C), and Emitter (E).
- A BJT allows a small current injected at its Base to control a much larger current flowing between the Emitter and Collector terminals, making the device capable of amplification and switching.
- Regions of Operation of BJT (NPN):

B-E Junction	B-C Junction	Region
Reverse	Reverse	Cut-off
Forward	Reverse	Active
Reverse	Forward	Inverse-active
Forward	Forward	Saturation



EE236 : Experiment 7 Dept. of EE, IIT-Bombay 2/13

Background Information (continued)




Figure: Current mechanisms in NPN BJT, Active Region

Note that in an NPN BJT, electrons are majority carriers and holes are minority carriers.

EE236: Experiment 7 Dept. of EE, IIT-Bombay 3/13 3/13

DC parameters of BJT

• Base Transport Factor (α_T) : The fraction of the minority carriers injected into the base that successfully diffuse across the width of the base and enter the collector.

$$\alpha_T = \frac{i_C}{i_E} \tag{1}$$

• Emitter Efficiency (γ) :

$$\gamma = \frac{i_{En}}{i_E} \tag{2}$$

Common Emitter Current Gain (β):

$$\beta = \frac{i_C}{i_B} \tag{3}$$



Components Necessary

The following components are needed in order to perform the experiment.

- BC547 BJT
- MT3S1 HBT
- Resistors (PART 1): $1k\Omega$, 470Ω
- Resistors (PART 2): $15k\Omega$, $18k\Omega$, $10k\Omega$, $1.2k\Omega$, 250Ω
- Potentiometer: $1k\Omega$
- Capacitor: 4.7uF
- Breadboard, Multimeters and connecting wires



BC547 BJT Pinout




Figure: BC547 BJT Pinout



PART I: BJT Parameters in CB configuration

- Plot output characteristics of CB configuration (I_C vs V_{CB} for different I_E).
- Determine the parameters α and β assuming $\gamma = 1$.
- Plot collector and base currents (I_C and I_B) against varying base emitter (V_{BE}) voltage at a fixed collector to base bias voltage (V_{CB}).




Figure: CB Circuit

Note: Take I_E from 3 mA to 9 mA in steps of 3 mA. (Ensure collector-base junction is reverse biased, V1 \geq 4V)



EE236 : Experiment 7 Dept. of EE, IIT-Bombay 7/13 7/13

PART II: Frequency response of BJT vs HBT

In this part, the following tasks are to be done:

- Obtain the frequency response of BJT in CE configuration.
- Obtain the frequency response of HBT in CE configuration.
- Plot combined gain vs. frequency response of both on a semi-log scale.



EE236: Experiment 7 Dept. of EE, IIT-Bombay 8/13 8/13

MT3S11 HBT Pinout




Figure: MT3S11 HBT Pinout



Frequency response of BJT - BC547 (1)

Use CE configuration to make an amplifier as shown below.




Figure: BJT CE Circuit

- Fix the DC bias operating point in the Common Emitter circuit as: $V_{CE} = 6.0V$ and $I_C = 12$ mA, $I_B = 50$ uA.
- Give input small signal as $V_i = 500 \text{ mV}$, peak to peak.

EE236 : Experiment 7 Dept. of EE, IIT-Bombay 10/1310 / 13

Frequency response of BJT - BC547 (2)

- Vary the frequency of input sinusoid. Frequency steps to be taken: {1k, 5k, 10k, 50k, 100k, 150k, 200k, 250k, 300k, 350k, 400k, 450k, 500k, 550k, 600k}.
- Measure Vout and observe the voltage gain at different frequencies.
- Plot the frequency response and find the 3-dB cutoff frequency.



EE236 : Experiment 7 Dept. of EE, IIT-Bombay 11/131

Frequency response of HBT (1)

Use CE configuration to make an amplifier as shown below.




Figure: HBT CE Circuit

- Fix the DC bias operating point in the Common Emitter circuit as: $V_{CE} = 3.5V$ and $I_C = 12$ mA, $I_B = 50$ uA.
- Give input small signal as $V_i = 500 \text{ mV}$, peak to peak.

EE236 : Experiment 7 Dept. of EE, IIT-Bombay 12/1312

Frequency response of HBT (2)

- Vary the frequency of input sinusoid. Frequency steps to be taken: {1k, 5k, 10k, 50k, 100k, 150k, 200k, 250k, 300k, 350k, 400k, 450k, 500k, 550k, 600k, 650k, 700k, 750k, 800k, 850k, 900k}.
- Measure Vout and observe the voltage gain at different frequencies.
- Plot the frequency response and find the 3-dB cutoff frequency.
- Compare the 3-dB frequency of HBT and BJT, Include in your report an explanation of why HBT exhibits superior performance at higher frequencies.



EE236: Experiment 7 Dept. of EE, IIT-Bombay 13/1313